



## ECOMAX 702

The ECOMAX 702 Utensil Washer offers the best wash result for hard baked-in dirt. Perfect for utensils like pots, pans, trays or nally tubs. Suitable for bakers, butchers and restaurants.

### HOBART ECOMAX 702 UTENSIL WASHER

- Rotating top and bottom wash system to distribute the wash water evenly over the dishes
- Deep-drawn wash tank bottom
- Thermostop-function for guaranteed rinse temperatures
- Removal of wash and rinse arms without any tools
- Easy access to all parts
- Electronic control
- Completely stainless steel
- Loading of high trays and pots: up to 630mm loading height
- 150mm floor clearance
- 120/360 sec cycle times
- Up to 30 cycles per hour



GET CASH BACK ON  
NEW MACHINERY IN  
YOUR TAX RETURN!\*

CONTACT OUR MACHINERY TEAM TO  
ENQUIRE TODAY!

*\*MBL recommends consulting with your tax accountant to discuss your eligibility for Temporary Full Expensing to get cash back on new machinery in your tax return.*